

Part No.	Description	Illustrated on Page Number	Part No.	Description	Illustrated on Page Number
○ 28A	Nut—knotted release screw	13	○ 49D	Stud-roller—drawslide lever	13
○ 29	Post—knotted release	13	○ 50	Spring—drawslide (post office trip)	13—15
○ 29A	Pin—knotted release post	13	○ 50A	Pin—grooved	13
△ □ ○ A30L	Stringholder assembly—light, regular		○ A51	Tip-up assembly	13
△ □ ○ A30H	Stringholder assembly—heavy, regular		○ 51A	Rivet—tip-up lever	13
△ □ ○ A30CL	Stringholder assembly—light, clamp models		○ 51L	Lever—tip-up	13
△ □ ○ A30CH	Stringholder assembly—heavy, clamp models		△ □ ○ 52	Stripper—(styles listed below)	13
△ □ ○ 30L	Stringholder sub-assembly—light, regular	14	△ □ ○ 52A	Stripper—light, regular	
△ □ 30H	Stringholder sub-assembly—heavy, regular		△ □ ○ 52B	Stripper—heavy, regular	
△ □ 30CL	Stringholder sub-assembly—light, clamp model		△ □ 52LA	Stripper—light, laundry	
△ □ 30CH	Stringholder sub-assembly—heavy, clamp model		△ □ 52LB	Stripper—heavy, laundry	
○ 30FS	Screw-stringholder mounting		○ 53	Screw-stripper	13
○ 30P	Pin—spring perch	14	○ 54	Spring-stripper	13
○ 30PP	Pin—stringholder locating	14	○ 55	Lever-riser	13
○ A31L	Knife trap assembly—long lever	14	○ 55A	Screw-riser lever stop	13
A31S	Knife trap assembly—short lever (for very heavy ply only)		○ 55B	Nut-riser lever stop screw	13
○ 31	Knife trap	14	○ 56	Guide—riser pin	13
○ 32L	Lever—long, knife trap	14	○ 56A	Screw—guide mounting	13
32S	Lever—short, knife trap (for very heavy ply only)		○ 57	Pin—riser	13
○ 33	Screw—knife trap pivot	14	58	Spring—trip	15
○ 33L	Washer-lock—pivot screw	14	○ 59	Bell-crank trip	15
○ 33N	Nut—pivot screw	14	○ 59PO	Bell-crank trip—regular	
○ 34	Rivet—knife trap	14	60A	Nut-pivot screw (clamp model & replacement)	
○ 35	Spring—knife trap	14	60	Screw-pivot, (clamp model & replacement on old style)	
○ 35A	Stud-knife trap spring	14	○ 61	Screw-pivot	15
○ 36	Knife	14	○ 61A	Nut-pivot screw	15
○ 37	Screw—knife mounting	14	○ 61B	Washer-lock—pivot screw	15
○ 38	Button—stringholder	14	62	Rod-trip—(sizes below)	17
○ 39L	Spring—light, stringholder button (for 10 ply and below)	14	○ 62PO	Rod-trip	15
39H	Spring, heavy, stringholder button (for 12 ply and above)		○ 62S	Rod-trip, short (23")	
○ 40	Nut—stringholder button	14	○ 62T	Rod-trip, medium (24 3/4")	
○ 41	Washer—stringholder button	14	□ 62U	Rod-trip, long (28 1/4")	
○ 42	Lever-release, stringholder button	14	62N	Nut-trip rod	17
○ 43	Screw-release lever	14	62W	Washer-trip rod	17
○ A45	Drawslide assembly—regular (sold with A47 only)	13	○ A63	Fork assembly—clutch	
A45C	Drawslide assembly—clamp type (sold with A47 only)	13	○ 63	Fork—clutch	15
A45D	Drawslide assembly—double headed type		○ 64	Roller-clutch fork	15
○ A47	Cap assembly—drawslide	13	○ 65	Screw—clutch fork roller	15—17
○ 47A	Roller—drawslide cap	13	○ 66H	Pin-clutch fork pivot (includes cotter pins)	15
○ 47B	Stud-roller—drawslide cap	13	○ 67	Bearing—lower	15
○ 47C	Screw—drawslide cap	13	○ 67S	Screw—lower bearing	15
○ 47D	Washer-lock—drawslide cap	13	□ A68	Loose table assembly	17
○ A49	Lever assembly—drawslide		○ 68P1	Pin—loose table retaining, for 3/4" diam. stud	16—17
○ 49A	Washer—lever retaining	13	68P2	Pin—loose table retaining, for 3/4" diam. stud	16
○ 49B	Screw—lever retaining	13	68S	Housing—ball bearing, double (loose table)	
○ 49C	Roller—drawslide lever	13	68S short	Housing—ball bearing, single (loose table)	
			69	Yoke—clamp	
			69R	Rod—yoke	
			69T	Screw—thumb, yoke clamp	
			70	Lever—short	
			70P	Pin—taper, short lever	
			70R	Roller—short lever	
			70S	Stud-roller—short lever	
			71	Lever—long	
			71LS	Stud—large, long lever	

○ Used in post office models, too. Order may be written with "P.O." appended to part number.

□ Must order with machine serial number. △ Specify twine size used. † Used with backgaged models.